



## GENUINE PARTS

### INSTALLATION INSTRUCTIONS

1. **DESCRIPTION:** Accent Lighting Kit
2. **APPLICATION:** Cube (2010)
3. **PART NUMBER:** 999F3 7W000
  - Front Footwell and Console Cupholder Accent Lighting

4. **KIT CONTENTS:**


Item	QTY	Description	Service Part Number
A	1	Control Module	999F3 VU000S2
B	1	Encoder	999F3 VU000S4
C	1	Front footwell light assembly	999F3 7W000S1
D	1	Cupholder light assembly	999F3 VU000S1
E	1	Installation Kit (Not Shown)	999F3 7W000S3
F	1	Power Cable (Not Shown)	
G	1	Knob	999F3 VU000S3




A



B



C



D



E

5. **TOOLS REQUIRED:**
- Trim stick
  - 10mm and 11mm sockets
  - #2 Phillips screwdriver
  - Protective cloth
  - Metric Ruler
  - Ratchet and 6" extension
  - 5/16", 3/16" and 9/32" drill bits, right angle drill
  - Electrical Tape; Masking tape
  - Scissors

6. **PRE-INSTALLATION CAUTIONS/NOTES:**
- Dealer Installation Recommended. Instructions refer to Service Manual.
  - Installation requires special tools.
  - This part is to be installed at a surface temperature of 65-100°F.
  - Remove and prepare templates from the end of Installation Instructions.



### CAUTION

- This accessory must only be installed as specified by these instructions.

# INSTALLATION INSTRUCTIONS - Accent Lighting Kit

## 7. INSTALLATION OVERVIEW:

Cube (2010 ~)



## 8. CRITICAL STEPS:

The following steps are critical and must be performed EXACTLY as specified to ensure proper installation:

- Location of the lights must be followed exactly as described in this instruction.
- Posi-Tap™ instructions must be specifically followed as described.

# INSTALLATION INSTRUCTIONS - Accent Lighting Kit

## 9. VEHICLE PREPARATION:

Cube (2010 ~)

- 1) Vehicle Preparation
  - a) Record customer radio presets.

	1	2	3	4	5	6
<b>A</b>						
<b>B</b>						
<b>C</b>						

- b) Apply parking brake.
- c) Turn off the ignition.
- d) Place A/T Shifter in Drive.
- e) Disconnect battery negative terminal.


**NOTE: USE CAUTION WHEN REMOVING/RE-INSTALLING TRIM COMPONENTS TO AVOID DAMAGE, SCRATCHES, BREAKING OF CLIPS AND/OR INTERIOR TRIM PANELS. MOVE ALL TRIM COMPONENTS TO A PROTECTED AREA.**

- 2) Remove the following interior parts as shown. Refer to the vehicle service manual.

- |   |                                       |
|---|---------------------------------------|
| a) Center console cup holder screw covers | e) Instrument LH lower cover (center) |
| b) Center console                         | f) Instrument lower cover (center)    |
| c) Fuse Box Cover                         | g) Front pillar finisher (LH)         |
| d) LH Instrument lower cover              | h) Glove Box                          |

## ⚠ WARNING

- DO NOT PRY FROM REAR EDGE OF FRONT PILLAR FINISHER TO AVOID DAMAGE TO SIDE AIRBAG.





# INSTALLATION INSTRUCTIONS - Accent Lighting Kit

## 10. INSTALLATION PROCEDURE:


Cube (2010 ~)

- 1) Tap Accessory Brown wire to Brown wire at LH A-Pillar.  
See steps 2-7 for tap install instructions.



- 2) Tap vehicle wire
  - a) Remove cap (slot side) from tap body.
  - b) Slide cap around vehicle wire.
  - c) Tighten the tap TIGHT with finger pressure.

**NOTE:**  
**DO NOT RE-USE THE TAP FOR SUBSEQUENT RE-INSTALLATION.**




- 3) Inspect the tap to ensure correct installation.

**NOTE:**  
**AVOID PUTTING PRESSURE ON THE WIRE AND TAP FOR THE REST OF THE INSTALL.**


# INSTALLATION INSTRUCTIONS - Accent Lighting Kit

## 10. INSTALLATION PROCEDURE:


Cube (2010 ~)



- 4) Install (4) pieces Foam Tape to Brown Accessory wire beginning 100mm from the end. Leave a 25mm gap between each piece.



- 5) Tap the Brown wire from the Accessory harness.
- Remove tap (non-pierce) side from tap.
  - Remove protective stub from wire.
  - Insert wire through the non-pierce side opening.
  - Spread the individual strands into a fan shape.
  - Insert wire into tap body and ensure it is all the way in.
  - Tighten the tap TIGHT with finger pressure.




- 6) Confirm installation of the tapped accessory wire.
- Inspect the tap to ensure correct installation.


# INSTALLATION INSTRUCTIONS - Accent Lighting Kit

## 10. INSTALLATION PROCEDURE:

Cube (2010 ~)




- 7) Secure the tap.
  - a) Secure tapped wire on the non-pierce side to an existing anchor point such as harness, clip, metal structure, etc. within 1" (25.4mm) with electrical tape ( $\geq 2$  revolutions).
  - b) Secure the body to an existing anchor point such as harness, clip, metal structure etc. nearby with electrical tape. ( $\geq 2$  revolutions).



- 8) Secure the connection
  - a) Add 4" cable tie to retain wire to existing harness.

**NOTE:**  
**LEAVE TIES LOOSE UNTIL POWER CABLE IS FULLY ROUTED.**



- 9) Route the Power Cable
  - a) Route the Power Cable down through the IP along the existing harness.
  - b) Route the Yellow, Blue and Black wires to the Junction Box.

**Do not fully tighten ties at this time**

# INSTALLATION INSTRUCTIONS - Accent Lighting Kit



## 10. INSTALLATION PROCEDURE:

Cube (2010 ~)

### CAUTION

- If vehicle wire is being used by another accessory, tap other accessory wire and not vehicle wire.

- 10) Tap Accessory Yellow wire to the Yellow wire, Pin 4 of Junction Box.  
See steps 2-7 for wire tap installation instructions.
- 11) Tap Accessory Blue wire to the Blue/Yellow wire, Pin 20 of Junction Box.  
See steps 2-7 for wire tap installation instructions.




- 12) Route power cable (Cont'd)
  - a) Route Power cable along existing harness.
  - b) Place 4" cable tie as shown.

**NOTE:**  
**LEAVE TIES LOOSE UNTIL POWER CABLE IS FULLY ROUTED.**

## INSTALLATION INSTRUCTIONS - Accent Lighting Kit


### 10. INSTALLATION PROCEDURE:

Cube (2010 ~)




- 13) a) Route Power cable along existing harness.
- b) Place 4" cable tie as shown.  
**Do not fully tighten ties at this time.**

**NOTE:**  
**LEAVE TIES LOOSE UNTIL POWER CABLE IS FULLY ROUTED.**



- 14) Route Power Cable (Cont'd)
- a) Route Power Cable across the I/P toward the center.




- 15) Route power cable (Cont'd)
- a) Route the power cable down to the center stack area.


# INSTALLATION INSTRUCTIONS - Accent Lighting Kit

## 10. INSTALLATION PROCEDURE:


Cube (2010 ~)



- 16) Prepare LH Instrument Lower Finisher.
- a) Mark Short bracket hole 35mm from panel edge, against rib.
  - b) Mark Long bracket hole 40mm from panel edge, against OBDII pocket.
  - e) Drill (2) 3/16" holes at marked locations.



- 17) Install the Brackets.
- a) Clean mounting areas with alcohol wipe.
  - b) Peel off double-sided tape liner from Brackets.
  - c) Install Brackets to lower finisher with holes aligned.
  - d) Install (2) Phillips screws from Kit.



- 18) Install Driver side Light Assembly.
- a) Clean mounting area with alcohol wipe.
  - b) Peel off double-sided tape liner from Light Assembly.
  - c) Press Assembly to Brackets with tape centered.
  - d) Install (4) 4" Cable Ties around wire, Light Assembly and Brackets. Trim excess tie.


# INSTALLATION INSTRUCTIONS - Accent Lighting Kit

## 10. INSTALLATION PROCEDURE:


Cube (2010 ~)

### CAUTION

- Use only the drill size specified below to avoid damage to Cupholder.
- Use a drill stop to avoid damage to the Cupholder.



- 19) Prepare cupholder for LEDs.
- a) Align template (A) to 2 ribs on cupholder.
  - b) Tape LED template to cupholder.
  - c) Mark and drill (2) 9/32" holes.




- 20) Prepare console for Encoder.
- a) Tape Encoder template (B) to console.
  - b) Mark and drill (1) 5/16" hole.


# INSTALLATION INSTRUCTIONS - Accent Lighting Kit

## 10. INSTALLATION PROCEDURE:


Cube (2010 ~)



- 21) Install cupholder LED's.
  - a) Snap in (2) LED lenses and retainers.
  - b) Clean LED mounting area with alcohol wipe.
  - c) Peel double-sided tape liner and place each cupholder light assembly as shown.



- 22) Install Encoder.
  - a) Insert Encoder in hole, routing wire as shown.
  - b) Install 11mm Lock Nut and Knob.




- 23) Route and retain console wiring.
  - a) Route encoder and LED wires as shown.
  - b) Install (2) pieces foam tape to secure wires to cupholder.


# INSTALLATION INSTRUCTIONS - Accent Lighting Kit

## 10. INSTALLATION PROCEDURE:

Cube (2010 ~)



- 24) Prepare Glove Box Assembly
- a) Locate and mark (2) holes aligned with existing Glove Box holes.
  - b) Drill (2) 5/16" holes.
  - c) Reinstall Glove Box Assembly.




- 25) Reinstall LH Lower Finisher and Ground
- a) Reinstall Finisher, OBDII connector and screw.
  - b) Attach Accessory GROUND eyelet under Hood Release Bolt.

# INSTALLATION INSTRUCTIONS - Accent Lighting Kit


## 10. INSTALLATION PROCEDURE:

Cube (2010 ~)




- 26) Route Passenger Side Light Assembly
- Route passenger side Light Assembly behind heater core as shown.
  - Carefully pull Light Assembly and wiring to passenger footwell area.

**NOTE:**  
**REVIEW PICTURES BEFORE MOUNTING LIGHTS. ENSURE LEDS ARE NOT OBSTRUCTED.**



- 27) Use a 4" Cable Tie to secure the Power Harness and Light harness to the vehicle cable.



- 28) Mount Passenger Side Light Assembly
- Clean I/P mounting surface with alcohol wipe.
  - Peel double-sided tape liners from Light Assembly.
  - Press Light Assembly under I/P with #6 on Light Assembly aligned to center Glove Box screw.


**NOTE:**  
**TO ASSIST IN CABLE TIE INSTALLATION, BEND CABLE TO HALF CIRCLE PRIOR TO FEEDING THROUGH HOLES.**

- Secure Light Assembly with (2) 11" Cable Ties through the previously drilled holes and around the light.
- Trim excess tie.


## INSTALLATION INSTRUCTIONS - Accent Lighting Kit

### 10. INSTALLATION PROCEDURE:

Cube (2010 ~)



- 29) Module preparation
- Peel tape liner from Adhesive Pad and adhere to the Module, covering screw head.



- 30) Connect and mount Module
- Place console in vehicle so accessory wiring can reach Module.
  - Connect (2) console accessory wires to Module.
  - Connect footwell light wires to Module.
  - Peel tape liner from Pad on Module and adhere to carpet below Center of I/P.
  - Peel tape liner and install foam tape over Module to carpet.
  - Bundle and tie remaining cable under IP using 4" Tie.
- 31) Verify there is no loose wiring.
- 32) Secure all Cable ties and snip ends.
- 33) Re-assemble vehicle in reverse order.
- 34) Perform Checklist test and inspection.

### CAUTION

- Use caution when removing/re-installing trim components to avoid damage, scratches, breaking of clips and/or interior trim panels.

## INSTALLATION INSTRUCTIONS - Accent Lighting Kit

### 11. CHECKLIST:

Prior to completion, verify the following:

- (1) Connect the battery negative terminal.
- (2) Turn the vehicle ignition switch to the "ACC" position, push lighting control knob, and confirm the Accent Lighting illuminates.
- (3) Turn the lighting control knob and confirm that the color changes through 20 variations.
- (4) Press and hold control knob for 3 seconds and confirm that the Accent Lighting enters "Demo Mode" and cycles through colors. Press knob again to exit demo mode.
- (5) Leaving the accessory ON, turn the Interior Room Lamp to "DOOR" and ignition switch OFF. Open the door and confirm the Accent Lighting illuminates.
- (6) Leaving the accessory ON, and the ignition switch OFF, close and lock the door using CDL or Key Fob (if equipped). Confirm that the Accent Lighting turns off.
- (7) Reset the radio presets to the recorded settings.
- (8) Place the Accent Lighting Quick Reference card in the glove box.
- (9) Check the trim for a proper flush fit after re-installing the interior components.
- (10) Clean the interior of the vehicle.
- (11) Inspect the vehicle interior and exterior for damage.

**For installation or technical questions, call Dealer Technical Support at: 866-559-0074.**

Posi-Tap™ is protected by patent # 5,228,875 5,695,369 5,868,589 6,692,313 Jap 2881414  
Aus 708700 Tia 103534 Can 2204826 Mex 200626 Korea 477279 China Z197105562.9 &  
others pending.