



GENUINE PARTS

INSTALLATION INSTRUCTIONS



INSTALLATION PROCEDURE:



- 1) Apply parking brake.
- 2) Put shift lever in "P" position for A/T and CVT or "1st" for M/T
- 3) Affix Drop Cloth
 - a) Open vehicle back door.
 - b) Affix the drop cloth using the Masking tape to protect the luggage room. See Fig. 1.

NOTE:


Be sure to cover the striker with the drop cloth.

- 4) Remove the vehicle parts
 - a) Remove back door trim. See. Fig. 2-1.
 - Remove 3 clips and back door finisher on each side.
 See.Fig. 2-1.
 - c) Remove the vehicle boot, and hold harness to hinge side of hole on each side.
 See.Fig. 2-2,Fig. 2-3.

NOTE:

The removed vehicle parts are to be reused. Be careful not to lose.

d) Pull back door down.



5) Align the template


- a) Align the template(LH)(F) at the back door hatch opening. See Fig. 3.
- b) Apply masking tape, to hold the template(LH)(F) in place.
 See Fig. 3.
- c) Punch the center of the (+)-slit of the template (LH)(F) using the center punch. (2 places) See Fig. 3.
- d) On the right side, align template (RH)(G) and punch in the same steps (g) to (i).


- 6) Drilled holes
 - a) Wrap masking tape around 3mm (1/8"),6mm(15/64")and 10mm (25/64") drill bits, approximately 10mm from the tip. See Fig. 4-2.
 - b) Drill 3mm (1/8") \rightarrow 6mm (15/64") \rightarrow 10mm(25/64") holes at the 4 marked locations on the back door. See Fig. 4-1.
 - c) Remove any sharp edges from the drilled holes with a debur tool.


ACAUTION

- Confirm that the harness is not in the way before you drill.
- Use debur tool with care regard to the hole diameter.

INSTALLATION PROCEDURE:







7) Compressed air

- a) Open back door.
- b) Remove metal shavings from inside back door with the air compressor and blowgun. See Fig. 5.
- c) Pull back door down.
- d) Apply rust preventative (P/N 999MP 9G001P) to the drilled holes. Let area dry thoroughly.

- Failure to apply rust preventative will result in red rust.
- 8) Insert grommets
 - a) Insert the protruding section of the grommet (LH)(D)
 / grommet (RH)(E) into the drilled holes. (2 places)
 See Fig. 6.


NOTE:

Grommets are left and right hand specific identified by L & R. See Fig. 6.

- 9) Mounting surface cleaning
 - a) Using a clean, lint free cloth and 100% alcohol, wipe any dirt and oil from the mounting surface. Let area dry thoroughly.
 See Fig. 7.

ACAUTION

• Do not remove rust preventative when cleaning.




¹⁰⁾ Roof spoiler Installation

 a) Insert and install the clip(C) by sliding it to the bracket on the backside of the roof spoiler (A). See Fig. 8.

- b) Remove approximately 30mm of tape liner A and B from double-sided tape on the roof spoiler(A).
 See Fig. 9.
- c) Fold tape liner onto the roof spoiler(A) surface and apply masking tape to ensure that the tape liner is accessible.See Fig. 9.
- d) Remove tape liner C from double-sided tape on the roof spoiler(A).

- Fully insert the clip(C) on the backside of the roof spoiler(A) into the grommet (LH)(D) /(RH)(E) until you hear the click sound.
 See Fig. 10.
- f) Open back door.
- g) Check to confirm nut insert on spoiler align with drilled hole. Adjust spoiler as necessary for proper alignment.
- h) Loosely install bolts(B) into the nuts. See Fig.11.



- i) Pull back door down.
- j) Check that the clearance at left and right hand is same.
 See Fig. 12.
- k) Pull out the tape liner A. Then push tape A toward vehicle front.
- I) Pull out the tape liner B. Then push tape B down.

m) Firmly apply 15lbf pressure to the arrow areas. See Fig.14.

- n) Open back door.
- o) Tighten bolts(B) into the nuts of the back door. (2 locations)
 See Fig.15.