



GENUINE PARTS

INSTALLATION INSTRUCTIONS


DESCRIPTION: Cargo Level Load Floor

APPLICATION: Kicks

PART NUMBER: T99C5 5RL0A

KIT CONTENTS:

Item	Qty.	Part Description
A	1	Cargo Level Load Floor
B	1	Installation Instruction Replacement Template



A



B

TOOLS REQUIRED:

- N/A

PRE-INSTALLATION WARNINGS, CAUTIONS, CRITICAL STEPS, and NOTES:

- To maintain the luster of your cargo level load floor, clean with a cloth as required using standard automotive vinyl, leather and upholstery cleaners or soap and water.


WARNING

- Your cargo level load floor is designed to transport normal cargo contents. Flammable or dangerous materials should not be transported in your vehicle at any time. If any corrosive chemicals are spilled on your cargo level load floor it should be cleaned as described above.


CAUTION

- Cargo Level Load Floor should be strapped in driving condition.
- 150Lb Max Load

INSTALLATION PROCEDURE:




- 1) Open hatch and place seats in folded position.
- 2) Remove any items from cargo area.



- 3) Place part into cargo area in either upright position or in flipped position as shown.

Note: Cargo Level Load Floor has a Seat Bracket Notch so part does not interfere with Seat Bracket in Flipped condition.

INSTALLATION PROCEDURE:



- 4) Secure part to vehicle using straps.
 - a) For upright position (shown), lift part to access D-ring anchor points.
 - b) Clip driver side strap hook to D-ring, then repeat for passenger side.